




How to fit DIY Homefit Sliding Doors




1. Screw top track into place flush with front of wardrobe frame.



2. Screw bottom track into place 12mm back from front edge of wardrobe frame.



3. Fitting the rear door first, lift the door into the top track at a slight angle before guiding the bottom wheels into the bottom track. The wheels need to be pushed up into the doors to do this as they are sprung,



4. The door height can be adjusted using a screwdriver